

PRINCIPLE OF OPERATION

This ball check valve pump is powered by compressed air and is a 1:1 pressure ratio design. It alternately pressurizes the inner side of one diaphragm chamber, while simultaneously exhausting the other inner chamber. This causes the diaphragms, which are connected by a common rod, to move endwise. Air pressure is applied over the entire surface of the diaphragm, while liquid is discharged from the opposite side. The diaphragm operates under a balanced condition during the discharge stroke, which allows the unit to be operated at discharge heads over 200 feet (61 meters) of water head.

Since the diaphragms are connected by a common rod, secured by plates to the center of the diaphragms, one diaphragm performs the discharge stroke, while the other is pulled to perform the suction stroke in the opposite chamber.

For maximum diaphragm life, keep the pump as close to the liquid being pumped as possible. Positive suction head in excess of 10 feet of liquid (3.048 meters) may require a back pressure regulating device. This will maximize diaphragm life.

Alternate pressuring and exhausting of the diaphragm chamber is performed by means of an externally mounted, pilot operated, four-way spool type air distribution valve. When the spool shifts to one end of the valve body, inlet air pressure is applied to one diaphragm chamber and the other diaphragm chamber exhausts. When the spool shifts to the opposite end of the valve body, the porting of chambers is reversed. The air distribution valve spool is moved by an internal pilot valve which alternately pressurizes one side of the air distribution valve spool, while exhausting the other side. The pilot valve is shifted at each end of the diaphragm stroke by the diaphragm plate coming in contact with the end of the pilot valve spool. This pushes it into position for shifting of the air distribution valve.

The chambers are manifolded together with a suction and discharge check valve for each chamber, maintaining flow in one direction through the pump.

This specially-fitted SandPIPER pump differs from standard units in that it utilizes four diaphragms instead of two. The two rod-connected diaphragms being the driver diaphragms, and the other two (outermost) diaphragms being the actual pumping diaphragms. Each driver diaphragm (of Neoprene or other elastomer), and the pumping diaphragm (of TFE), are separated by a chamber filled with liquid. This transmits the reciprocating motion of the driver diaphragm to the pumping diaphragm. The TFE pumping diaphragms create alternating suction and discharge action to each outer diaphragm chamber. The pumping diaphragms are the only ones in contact with the liquid being pumped.

INSTALLATION & START-UP

Locate the pump as close to the product being pumped as possible, keeping suction line length and number of fittings to a minimum. Do not reduce line size.

For installations of rigid piping, short flexible sections of hose should be installed between pump and piping. This reduces vibration and strain to the piping system. A Warren Rupp Tranquilizer® surge suppressor is recommended to further reduce pulsation in flow.

This pump was tested at the factory prior to shipment and is ready for operation. It is completely self-priming from a dry start for suction lifts of 10-15 feet (35 meters) or less. For suction lifts exceeding 15 feet of liquid, fill the chambers with liquid prior to priming.

AIR SUPPLY

Air supply pressures cannot exceed 125 psi (8.61 bar). Connect the pump air inlet to an air supply of sufficient capacity and pressure required for desired performance. When the air line is solid piping, use a short length of flexible hose (not less than 3/4" [19mm] in diameter) between pump and piping to eliminate strain to pipes. Use of a Warren Rupp Filter/Regulator in the air line is recommended.



IMPORTANT

Read these safety warnings and instructions in this manual completely, before installation and start-up of the pump. It is the responsibility of the purchaser to retain this manual for reference. Failure to comply with the recommendations stated in this manual will damage the pump, and void factory warranty.



CAUTION

Before pump operation, inspect all gasketed fasteners for looseness caused by gasket creep. Re-torque loose fasteners to prevent leakage. Follow recommended torques stated in this manual.



WARNING

Before maintenance or repair, shut off the compressed air line, bleed the pressure, and disconnect the air line from the pump. The discharge line may be pressurized and must be bled of its pressure.



WARNING

In the event of diaphragm rupture, pumped material may enter the air end of the pump, and be discharged into the atmosphere. The air exhaust must be piped to an appropriate area for safe disposition.



WARNING

Take action to prevent static sparking. Fire or explosion can result, especially when handling flammable liquids. The pump, piping, valves, containers or other miscellaneous equipment must be grounded.

AIR INLET & PRIMING

For start-up, open an air valve approximately 1/2" to 3/4" turn. After the unit primes, an air valve can be opened to increase flow as desired. If opening the valve increases cycling rate, but does not increase flow rate, cavitation has occurred, and the valve should be closed slightly.

For the most efficient use of compressed air and the longest diaphragm life, throttle the air inlet to the lowest cycling rate that does not reduce flow.

AIR EXHAUST

If a diaphragm fails, the pumped liquid or fumes can enter the air end of the pump, and be exhausted into the atmosphere. When pumping hazardous or toxic materials, pipe the exhaust to an appropriate area for safe disposition.

This pump can be submerged if materials of construction are compatible with the liquid. The air exhaust must be piped above the liquid level. Piping used for the air exhaust must not be smaller than 1" (2.54 cm). Reducing the pipe size will restrict air flow and reduce pump performance. When the product source is at a higher level than the pump (flooded suction), pipe the exhaust higher than the product source to prevent siphoning spills.

Freezing or icing of the air exhaust can occur under certain temperature and humidity conditions. Use of an air dryer should eliminate most icing problems.

BETWEEN USES

When used for materials that tend to settle out or transform to solid form, the pump should be completely flushed after each use, to prevent damage. Product remaining in the pump between uses could dry out or settle out. This could cause problems with valves and diaphragms at re-start. In freezing temperatures, the pump must be drained between uses in all cases.

CHECK VALVE SERVICING

Need for inspection or service is usually indicated by poor priming, unstable cycling, reduced performance or the pump's cycling but not pumping. (See Fig. 3)

Inspect the surfaces of both check valve and seat for wear or damage that could prevent proper sealing. If pump is to prime properly, valves must seat air tight.

DIAPHRAGM SERVICING


Driver Diaphragms:

Drain the intermediate diaphragm housing (Item 36) by removing the pipe plug directly beneath and behind the mounting flange. This port is also used for the optional Electronic Leak Detector (Warren Rupp p/n 032-017-000 115 volt or p/n 032-018-000 220 volt). Remove four bolts securing the manifold flange to the chamber. Remove eight nuts (Item 42) securing the inner diaphragm chamber (Item 22) and remove the outer driver diaphragm assembly by pulling it axially off the studs. This permits inspection of the Virgin PTFE diaphragm and the driver diaphragm. Pumping diaphragm chambers need not be separated for access to the driver diaphragm. Loosen the plate which secures the diaphragm and plate to the rod by keeping the diaphragm engaged with the inner diaphragm chamber (Item 22) by inserting two or three capscrews through the bolt holes so that the diaphragm cannot rotate when loosening. The diaphragm plates, diaphragm and bumper will now come off the assembly. Repeat all actions if the other diaphragm needs to be inspected or replaced.

NOTE: See "Filling of Driver Chamber with Liquid" for the correct procedure to recharge the pump for operation.

Reassembly is the reverse of the tear down. During reassembly, be sure that the rubber bumper is on the rod on each side (see Figure 5). Install the diaphragm with the natural bulge to the outside as marked on the diaphragm. Install the heavier plate on the outer side of the diaphragm. Be sure that the large radius side of each plate is toward the diaphragm. Place the sealing washer between the inner diaphragm plate and the end of the rod. Tighten the plate to approximately 25 ft. lbs. (33.89 Newton meters). Torque while allowing the diaphragm to turn freely with the plate. Hold the opposite side with a wrench on the plate to prevent rotation of the rod. If the opposite chamber is assembled, this will not be necessary.

When reassembling the outer chambers and the manifold, the bolts securing the manifold flange to the chamber should be snugged prior to tightening the manifold flange. Finish tightening the manifold flange bolts after the chamber bolting is secured.



Pumping Diaphragms:

It is recommended that the above procedure be followed to the point of removing the pumping diaphragm assembly from the pumping unit. Remove eight hex nuts which allow the outer diaphragm chamber to be lifted from the assembly exposing the PTFE diaphragm. The PTFE diaphragm can now be lifted from the bolts. The black gasket (Item 37) is designed to prevent movement and supplement the sealing of the PTFE diaphragm to retain the driver liquid, and to seal the wetted chamber.

The reassembly should be in reverse as follows.

Install the rubber diaphragm gasket inside the hex head capscrews protruding through inner chamber. Install PTFE diaphragm in place.

Snug down the outer diaphragm housing (Item 39) evenly torqued on all eight bolts, alternating from one side to the other in the process. After this subassembly is completed and reinstalled on the pump as it was removed, the pump should be tested prior to the reinstallation on the job to make sure the capscrews and nuts are torqued down properly to prevent leakage around the PTFE diaphragm surfaces. Do not overtighten these bolts. PTFE has a tendency to cold flow. Torque at 200 inch/pounds (22.59 Newton meters).

A NOTE ABOUT AIR VALVE LUBRICATION


The SandPIPER pump's pilot valve and main air valve assemblies are designed to operate WITHOUT lubrication. This is the preferred mode of operation. There may be instances of personal preference, or poor quality air supplies when lubrication of the compressed air supply is required. The pump air system will operate with properly lubricated compressed air supplies. Proper lubrication of the compressed air supply would entail the use of an air line lubricator (available from Warren Rupp) set to deliver one drop of 10 wt., non-detergent oil for every 20 SCFM of air the pump consumed at its point of operation. Consult the pump's published Performance Curve to determine this.

It is important to remember to inspect the sleeve and spool set routinely. It should move back and forth freely. This is most important when the air supply is lubricated. If a lubricator is used, oil accumulation will, over time, collect any debris from the compressed air. This can prevent the pump from operating properly.

Water in the compressed air supply can create problems such as icing or freezing of the exhaust air causing the pump to cycle erratically, or stop operating. This can be addressed by using a point of use air dryer to supplement a plant's air drying equipment. This device will remove excess water from the compressed air supply and alleviate the icing or freezing problem.

ESADS: EXTERNALLY SERVICEABLE AIR DISTRIBUTION SYSTEM

Please refer to the exploded view drawing and parts list in the Service Manual supplied with your pump. If you need replacement or additional copies, contact your local Warren Rupp Distributor, or the Warren Rupp factory Literature Department at the number shown below. To receive the correct manual, you must specify the MODEL and TYPE information found on the name plate of the pump.



MODELS WITH 1" SUCTION/DISCHARGE OR LARGER, AND METAL CENTER SECTIONS

The main air valve sleeve and spool set is located in the valve body mounted on the pump with four hex head capscrews. The valve body assembly is removed from the pump by removing these four hex head capscrews.

With the valve body assembly off the pump, access to the sleeve and spool set is made by removing four hex head capscrews (each end) on the end caps of the valve body assembly. With the end caps removed, slide the spool back and forth in the sleeve. The spool is closely sized to the sleeve and must move freely to allow for proper pump operation. An accumulation of oil, dirt or other contaminants from the pump's air supply, or from a failed diaphragm, may prevent the spool from moving freely. This can cause the spool to stick in a position that prevents the pump from operating. If this is the case, the sleeve and spool set should be removed from the valve body for cleaning and further inspection.

Remove the spool from the sleeve. Using an arbor press or bench vise (with an improvised mandrel), press the sleeve from the valve body. Take care not to damage the sleeve. At this point, inspect the o-rings on the sleeve for nicks, tears or abrasions. Damage of this sort could happen during assembly or servicing. A sheared or cut o-ring can allow the pump's compressed air supply to leak or bypass within the air valve assembly, causing the pump to leak compressed air from the pump air exhaust or not cycle properly. This is most noticeable at pump dead head or high discharge pressure conditions. Replace any of these o-rings as required or set up a routine, preventive maintenance schedule to do so on a regular basis. This practice should include cleaning the spool and sleeve components with a safety solvent or equivalent, inspecting for signs of wear or damage, and replacing worn components.

To re-install the sleeve and spool set, lightly lubricate the o-rings on the sleeve with an o-ring assembly lubricant or lightweight oil (such as 10 wt. air line lubricant). Press the set into the valve body easily, without shearing the o-rings. Re-install one end cap, gasket and bumper on the valve body. Using the arbor press or bench vise that was used in disassembly, press the sleeve back into the valve body. You may have to clean the surfaces of the valve body where the end caps mount. Material may remain from the old gasket. Old material not cleaned from this area may cause air leakage after reassembly. Take care that the bumper stays in place allowing the sleeve to press in all the way. Re-install the spool, keeping the counter-bored end toward you, and install the spring and the opposite end cap, gasket and bumper on the valve body. After inspecting and cleaning the gasket surfaces on the valve body and intermediate, re-install the valve body on the pump using new gaskets. Tighten the four hex head capscrews evenly and in an alternating cross pattern.

MODELS WITH 1" SUCTION/DISCHARGE OR LARGER, AND NON-METAL CENTER SECTIONS

The main air valve sleeve and spool set is located in the valve body mounted on the pump with four hex head capscrews. The valve body assembly is removed from the pump by removing these four hex head capscrews.

With the valve body assembly off the pump, access to the sleeve and spool set is made by removing a retaining ring (each end) securing the end cap on the valve body assembly. With the end caps removed, slide the spool back and forth in the sleeve. The spool is closely sized to the sleeve and must move freely to allow for proper pump operation. An accumulation of oil, dirt or other contaminants from the pump's air supply, or from a failed diaphragm, may prevent the spool from moving freely. This can cause the spool to stick in a position that prevents the pump from operating. If this is the case, the sleeve and spool set should be removed from the valve body for cleaning and further inspection.

Remove the spool from the sleeve. Using an arbor press or bench vise (with an improvised mandrel), press the sleeve from the valve body. Take care not to damage the sleeve. At this point, inspect the o-rings on the sleeve for nicks, tears or abrasions. Damage of this sort could happen during assembly or servicing. A sheared or cut o-ring can allow the pump's compressed air supply to leak or bypass within the air valve assembly, causing the pump to leak compressed air from the pump air exhaust or not cycle properly. This is most noticeable at pump dead head or high discharge pressure conditions. Replace any of these o-rings as required or set up a routine, preventive maintenance schedule to do so on a regular basis. This practice should include cleaning the spool and sleeve components with a safety solvent or equivalent, inspecting for signs of wear or damage, and replacing worn components.

To re-install the sleeve and spool set, lightly lubricate the o-rings on the sleeve with an o-ring assembly lubricant or lightweight oil (such as 10 wt. air line lubricant). Press the set into the valve body easily, without shearing the o-rings. Re-install one end cap, and retaining ring on the valve body. Using the arbor press or bench vise that was used in disassembly, press the sleeve back into the valve body. Re-install the spool, keeping the counter-bored end toward you, and install the spring, opposite end cap and retaining ring on the valve body. After inspecting and cleaning the gasket surfaces on the valve body and intermediate, re-install the valve body on the pump using new gaskets. Tighten the four hex head capscrews evenly and in an alternating cross pattern, at 150 in./lbs. (16.94 Newton meters).

PILOT VALVE

The pilot valve assembly is accessed by removing the main air distribution valve body from the pump and lifting the pilot valve body out of the intermediate housing (see Figure 8).

Most problems with the pilot valve can be corrected by replacing the o-rings. Always grease the spool prior to inserting it into the sleeve. If the sleeve is removed from the body, reinsertion must be at the chamfered side. Grease the o-rings to slide the sleeve into the valve body. Securely insert the retaining ring around the sleeve. When reinserting the pilot valve, push both plungers (located inside the intermediate bracket) out of the path of the pilot valve spool ends to avoid damage.

PILOT VALVE ACTUATOR

Bushings for the pilot valve actuators are held in the inner chambers with retaining rings. An o-ring is behind each bushing. If the plunger has any sideways motion check o-rings and bushings for deterioration/wear. The plunger may be removed for inspection or replacement. First remove the air distribution valve body and the pilot valve body from the pump. The plungers can be located by looking into the intermediate. It may be necessary to use a fine piece of wire to pull them out. The bushing can be removed from the inner chamber by removing the outer chamber assembly. Replace the bushings if pins have bent (see Figure 9 and Figure 10).

FILLING OF DRIVER CHAMBER WITH LIQUID

The driver chambers are filled at the factory with distilled water.

If you need to substitute another liquid to prevent system contamination, first consult the factory for chemical compatibility with pump construction.

Follow the steps listed below to replace the liquid in the pump after disassembly or liquid loss:

1. Filling is accomplished through the pipe plugs at the top of the liquid chamber. Drain ports are at the bottom of the liquid chamber.
2. After the driver fluid has been emptied from the pump, the driver diaphragms will naturally come to center.
3. Remove the entire manifold assembly exposing the ports in the outer diaphragm chambers.
4. Fill either side with 722 MI. or 24.6 fluid oz. by volume with the driver liquid. It is imperative that the driver liquid chambers be filled with the correct amount of driver liquid as too little or too much will cause premature diaphragm failure and erratic pumping.
5. After filling with the proper amount of liquid, if the liquid does not come to the top of the fill hole, pressure should be applied to the PTFE diaphragm with a blunt tool through the material flow port in the outer chamber until the liquid comes to the top. If the main air valve body and pilot valve are removed, the diaphragm rod will be visible in the intermediate bracket. The hole in the diaphragm rod will assist manual movement. Use a long taper punch to move the diaphragm rod.
6. When the driver fluid rises to the top of the fill plug hole, apply pipe dope to the pipe plug, and thread it into the chamber plug hole. (Do not use PTFE tape.) Keep pressure on the PTFE diaphragm until the pipe plug is tight to prevent air from drawing back into the chamber.
7. Repeat the filling procedure for opposite side.

TROUBLESHOOTING

1. Pump will not cycle

- A. Check to make sure the unit has enough pressure to operate and that the air inlet valve is open.
- B. Check the discharge line to insure that the discharge line is neither closed nor blocked.

C. If the spool in the air distribution valve is not shifting, check the main spool. It must slide freely.

D. Excessive air leakage in the pump can prevent cycling. This condition will be evident. Air leakage into the discharge line indicates a ruptured diaphragm. Air leakage from the exhaust port indicates leakage in the air distribution valve. See further service instructions.

E. Blockage in the liquid chamber can impede movement of diaphragm.

2. Pump cycles but will not pump

A. Suction side of pump pulling in air. Check the suction line for air leaks and be sure that the end of the suction line is submerged. Check flange bolting. Check valve flanges and manifold to chamber flange joints.

B. Make certain the suction line or strainer is not plugged. Restriction at the suction is indicated by a high vacuum reading when a vacuum gauge is installed in the suction line.

C. Check valves may not be seating properly. To check, remove the suction line and cover the suction port with your hand. If the unit does not pull a good suction (vacuum), the check valves should be inspected for proper seating.

D. Static suction lift may be too high. Priming can be improved by elevating the suction and discharge lines higher than the check valves and pouring liquid into the unit through the suction inlet. When priming at high suction lifts or with long suction lines operate the pump at maximum cycle rate.

E. Incorrect driver fluid level or unprimed air in the chamber can cause poor performance.

3. Low performance

A. Capacity is reduced as the discharge pressure increases, as indicated on the performance curve. Performance capability varies with available inlet air supply. Check air pressure at the pump inlet when the pump is operating to make certain that adequate air supply is maintained.

B. Check vacuum at the pump suction. Capacity is reduced as vacuum increases. Reduced flow rate due to starved suction will be evident when cycle rate can be varied without change in capacity. This condition will be more prevalent when pumping viscous liquids. When pumping thick, heavy materials the suction line must be kept as large in diameter and as short as possible, to keep suction loss minimal.

C. Low flow rate and slow cycling rate indicate restricted flow through the discharge line. Low flow rate and fast cycling rate indicate restriction in the suction line or air leakage into suction.

D. Unstable cycling indicates improper check valve seating on one chamber. This condition is confirmed when unstable cycling repeats consistently on alternate exhausts. Cycling that is not consistently unstable may indicate partial exhaust restriction due to freezing and thawing of exhaust air. Use of an anti-freeze lubricant in an air line lubricator should solve this problem.

E. Incorrect driver fluid level or unprimed air in the chamber can cause poor performance.

For additional information, see the Warren Rupp Troubleshooting Guide.

WARRANTY

This pump is warranted for a period of five years against defective material and workmanship. Failure to comply with the recommendations stated in this manual voids all factory warranty.

RECOMMENDED WARREN RUPP ACCESSORIES TO MAXIMIZE PUMP PERFORMANCE:

- **Tranquilizer® Surge Suppressor: For nearly pulse-free flow.**
- **Warren Rupp® Filter/Regulator: For modular installation and service convenience.**
- **Warren Rupp Speed Control: For manual or programmable process control. (Manual adjustment or 4-20mA reception.)**


For more detailed information on these accessories, contact your local Warren Rupp Factory-Authorized Distributor, or Warren Rupp corporate headquarters.

Grounding The Pump


⚠ WARNING ⚠

Take action to prevent static sparking. Fire or explosion can result, especially when handling flammable liquids. The pump, piping, valves, containers or other miscellaneous equipment must be grounded.

One eyelet is installed to a true earth ground.



One eyelet is fastened to the pump hardware.



This 8 foot long (244 centimeters) Ground Strap, part number 920-025-000 can be ordered as a service item.

To reduce the risk of static electrical sparking, this pump must be grounded. Check the local electrical code for detailed grounding instruction and the type of equipment required, or in the absence of local codes, an industry or nationally recognized code having jurisdiction over specific installations.

ITEM NO.	PART NO.	DESCRIPTION	QTY.
2	165-042-157	Cap, Valve Body	1
3	170-063-115	Capscrew, Hex Head	1
4	901-035-115	Washer, Flat	7
5	542-001-115	Nut, Square	1
6	170-033-115	Capscrew, Hex Head	4
7	901-005-115	Washer, Flat	4
8	360-058-360	Gasket, Valve Cap	1
9	095-051-558	Body, Spool Valve	1
10	031-083-000	Sleeve & Spool Set w/Pins	1
11	165-078-147	Cap, End	2
12	675-043-115	Ring, Retaining	2
13	560-058-360	O-Ring	8
14	530-036-000	Muffler	1
15	360-057-360	Gasket	1
16	095-074-000	Pilot Valve Body Assembly¹	1
16-A	095-071-551	Pilot Valve Body	1
16-B	755-025-000	Sleeve (with O-Ring)	1
16-C	560-033-360	O-Ring (Sleeve)	4
16-D	775-014-000	Spool (with O-Ring)	1
16-E	560-023-360	O-Ring (Spool)	4
16-F	675-037-080	Retaining Ring	1
17	360-056-379	Gasket	1
18	114-007-157	Bracket, Intermediate	1
19	560-040-360	O-Ring	2
20	675-040-360	Ring, Sealing	2
21	170-043-115	Capscrew, Hex Head	6
22	196-043-157	Chamber, Inner	1
23	196-042-157	Chamber, Inner	1
24	070-012-170	Bearing, Sleeve	2
25	720-010-375	Seal, U-Cup	2
26	560-001-379	O-Ring	2
27	135-034-506	Bushing	2
28	675-042-115	Ring, Retainer	2
29	620-007-114	Plunger, Actuator	2
30	685-039-120	Rod, Diaphragm	1
31	901-012-180	Washer, Sealing	2
32	132-019-360	Bumper, Diaphragm	2
33	612-022-330	Plate, Inner	2
34	286-008-365	Diaphragm	2
	286-008-363	Diaphragm	2
35	612-101-110	Plate, Outer	2
36	196-023-000	Chamber Assembly	2
37	360-039-365	Gasket, Diaphragm	2
	360-039-363	Gasket, Diaphragm	2
38	286-009-604	Diaphragm	2
38	286-009-604	Diaphragm	2

Repair Parts shown in **bold face (darker)** type are more likely to need replacement after extended periods of normal use. The pump owner may prefer to maintain a limited inventory of these parts in his own stock to reduce repair downtime to a minimum.

IMPORTANT: When ordering repair parts always furnish pump model number, serial number and type number.

MATERIAL CODES
The Last 3 Digits of Part Number

000...Assembly, sub-assembly;
and some purchased items
010...Cast Iron
015...Ductile Iron
025...Music Wire
080...Carbon Steel, AISI B-1112
100...Alloy 20
110...Alloy Type 316 Stainless Steel
112...Alloy "C"
114...303 Stainless Steel
115...301/302/304 Stainless Steel
120...416 Stainless Steel (Wrought Martensitic)
148...Hardcoat Anodized Aluminum
150...6061-T6 Aluminum
151...6063-T6 Aluminum
154...Almag 35 Aluminum
155 or 156...356-T6 Aluminum
157...Die Cast Aluminum Alloy #380
159...Anodized Aluminum
162...Brass, Yellow, Screw Machine Stock
170...Bronze, Bearing Type, Oil Impregnated
180...Copper Alloy
330...Plated Steel
331...Chrome Plated Steel
332...Electroless Nickel Plated
335...Galvanized Steel
356...Injection Molded Hytrel
357...Rupplon (Urethane Rubber)
358...E.P.D.M. (Food Grade)
359...Polyurethane
360...Buna-N Rubber. Color coded: RED
363...Viton (Fluorel). Color coded: YELLOW
364...E.P.D.M. Rubber. Color coded: BLUE
365...Neoprene Rubber. Color coded: GREEN
366...Food Grade Nitrile. Color coded: WHITE
375...Fluorinated Nitrile
379...Conductive Nitrile
405...Cellulose Fibre
408...Cork and Neoprene
425...Compressed Fibre
440...Vegetable Fibre
500...Delrin 500
501...Delrin 570
520...Injection Molded PVDF, Natural
Color, Food Grade/USDA Acceptable
541...Nylon, Glass Filled
550...Polyethylene
551...Polypropylene
552...Unfilled Polypropylene
555...PVC
558...Conductive HDPE
570...Rulon II
580...Ryton
590...Valox
600...PTFE (virgin material) Tetrafluoroethylene (TFE)
603...Blue Gylon
604...PTFE, Diaphragm
608...Conductive PTFE
610...PTFE Encapsulated Silicon
611...PTFE Encapsulated Viton
632...Neoprene Rupplon
633...Viton/PTFE
634...E.P.D.M./PTFE
636...White Nitrile/PTFE
Delrin, Viton and Hytrel are registered tradenames of E.I. DuPont.
Gylon is a registered tradename of Garlock, Inc.
Nylatron is a registered tradename of Polymer Corporation.
Rulon II is a registered tradename of Dixon Industries Corp.
Ryton is a registered tradename of Phillips Chemical Company.
Valox is a registered tradename of General Electric Company.
SandPIPER, Warren Rupp, Tranquilizer, Rupplon are registered tradenames of Warren Rupp, Inc.

¹Available in Kit Form. Order P/N 031-060-000 which includes items 8, 15, 17, 29, 45.

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
39	196-021-110	Chamber, Outer	2
	196-021-156	Chamber, Outer	2
40	170-029-115	Capscrew, Hex Head	16
41	900-004-115	Washer, Lock	26
42	545-004-115	Nut, Hex	42
43	618-003-110	Pipe, Plug	8
44	115-071-080	Brk't. Foot, Base	1
45	132-022-360	Bumper	2
46	350-002-360	Foot, Rubber	4
47	706-013-330	Screw, Machine	4
48	547-002-330	Nut, Stop	4
49	170-045-115	Capscrew, Hex Head	4
50	905-001-015	Washer, Taper	4
51	360-030-600	Gasket, Manifold	2
52	171-010-115	Capscrew, Flanged	4
53	170-047-332	Capscrew, Hex Head	6
54	334-013-157	Porting Flange	2
	334-013-110	Porting Flange	2
	334-013-157E	Porting Flange (BSP)	2
	334-013-110E	Porting Flange (BSP)	2
55	360-031-608	Gasket, Flange	4
56	050-011-600	Ball, Check Valve	4
57	722-047-110	Seat, Check Ball (Discharge)	2
58	518-020-110	Manifold	1
	518-020-156	Manifold	1
60	807-024-115	Stud	16
61	618-003-330	Pipe Plug	3
65	286-015-604	Diaphragm, Overlay	2
66	132-028-552	Bumper, Spool	2
68	210-008-330	Clip, Safety	1
69	560-029-360	O-Ring	2
70	255-012-335	Coupling 3/4" NPT (Exhaust Port)	1

ITEMS NOT SHOWN:
031-111-558


Valve Body Assembly
(Includes items 9, 10,
11, 12, 13, 66, 68 & 69)

Repair Parts shown in **bold face (darker)** type are more likely to need replacement after extended periods of normal use. The pump owner may prefer to maintain a limited inventory of these parts in his own stock to reduce repair downtime to a minimum.

IMPORTANT: When ordering repair parts always furnish pump model number, serial number and type number.

MATERIAL CODES
The Last 3 Digits of Part Number

000...Assembly, sub-assembly;
and some purchased items
010...Cast Iron
015...Ductile Iron
025...Music Wire
080...Carbon Steel, AISI B-1112
100...Alloy 20
110...Alloy Type 316 Stainless Steel
112...Alloy "C"
114...303 Stainless Steel
115...301/302/304 Stainless Steel
120...416 Stainless Steel (Wrought Martensitic)
148...Hardcoat Anodized Aluminum
150...6061-T6 Aluminum
151...6063-T6 Aluminum
154...Almag 35 Aluminum
155 or 156...356-T6 Aluminum
157...Die Cast Aluminum Alloy #380
159...Anodized Aluminum
162...Brass, Yellow, Screw Machine Stock
170...Bronze, Bearing Type, Oil Impregnated
180...Copper Alloy
330...Plated Steel
331...Chrome Plated Steel
332...Electroless Nickel Plated
335...Galvanized Steel
356...Injection Molded Hytrel
357...Rupplon (Urethane Rubber)
358...E.P.D.M. (Food Grade)
359...Polyurethane
360...Buna-N Rubber. Color coded: RED
363...Viton (Fluorel). Color coded: YELLOW
364...E.P.D.M. Rubber. Color coded: BLUE
365...Neoprene Rubber. Color coded: GREEN
366...Food Grade Nitrile. Color coded: WHITE
375...Fluorinated Nitrile
379...Conductive Nitrile
405...Cellulose Fibre
408...Cork and Neoprene
425...Compressed Fibre
440...Vegetable Fibre
500...Delrin 500
501...Delrin 570
520...Injection Molded PVDF, Natural
Color, Food Grade/USDA Acceptable
541...Nylon, Glass Filled
550...Polyethylene
551...Polypropylene
552...Unfilled Polypropylene
555...PVC
558...Conductive HDPE
570...Rulon II
580...Ryton
590...Valox
600...PTFE (virgin material) Polytetrafluoroethylene (PTFE)
603...Blue Gylon
604...PTFE, Diaphragm
608...Conductive PTFE
610...PTFE Encapsulated Silicon
611...PTFE Encapsulated Viton
632...Neoprene Rupplon
633...Viton/PTFE
634...E.P.D.M./PTFE
636...White Nitrile/PTFE
Delrin, Viton and Hytrel are registered tradenames of E.I. DuPont.
Gylon is a registered tradename of Garlock, Inc.
Nylatron is a registered tradename of Polymer Corporation.
Rulon II is a registered tradename of Dixon Industries Corp.
Ryton is a registered tradename of Phillips Chemical Company.
Valox is a registered tradename of General Electric Company.
SandPIPER, Warren Rupp, Tranquilizer, Rupplon are registered tradenames of Warren Rupp, Inc.



©2004 Warren Rupp, Inc. All rights reserved.

©SandPIPER, Warren Rupp, Tranquilizer are registered trademarks of Warren Rupp, Inc.

©Neverseize is a registered trademark of Loctite.

Printed in U.S.A.